




Installation Instructions



Unvented hot water storage cylinders
for use with Vaillant boilers

Vaillant Vantage 120
Vaillant Vantage 150
Vaillant Vantage 200



 EVALUATION & TESTING	
C E N T R E	
Test Report No. 2140100	
Certificate No. ETC 00394	
<small>Assessed and found to comply with the requirements of the Building Regulations for unvented hot water storage systems.</small>	
	
WBS Approval No. 9411064	

	Page
1 Description	2
2 Technical data	5
3 Dimensions	7
4 Applications	10
5 Functional diagrams	11
5.1 Functional diagram of the primary circuit	11
5.2 Functional diagram of the secondary connections	12
6 Functional description	13
6.1 D.H.W. Temperature Control	13
6.2 C.H. Control	13
6.3 Primary Circuit	13
6.4 Secondary System	14
6.5 Immersion Heater	14
6.6 Secondary Return	14
7 Installation requirements	15
7.1 Siting	15
7.2 Mains Water Pressure	16
7.3 Secondary System	17
7.4 Pipework - Primary Circuit	18
7.5 Discharge Pipework	19
7.5.1 High Level Termination	20
8 Installation procedure	21
8.1 Primary pipework	21
8.2 Secondary system Pipework	22
8.3 Safety valve discharge pipework	23
8.4 Electrical connections and controls	25
8.4.1 Immersion Heater	25
8.4.2 VANTAGE Electrical Connections and Controls	25
8.4.3 Control options - system wiring scheme	26
9 Commissioning	28
9.1 Filling Secondary D.H.W. Circuit	28
9.2 Filling the Primary Circuit	29
9.3 Operating the Vaillant Boiler	29
9.4 User's Instructions	30
10 Maintenance	31
11 Fault Finding	32

We cannot accept responsibility for any damage which may occur as a result of non-observance of these instructions. Subject to alteration.

1 Description

The VANTAGE range of unvented hot water storage cylinders are indirectly heated cylinders which are designed for use with Vaillant gas boilers **only**. The VANTAGE must NOT be installed with boilers supplied by any other manufacturer.

VANTAGE cylinders are available in three sizes of 120, 150 and 200 litre nominal capacity. The cylinders are of glass lined steel construction, insulated with CFC free foam and enclosed in a decorative sheet metal casing. They are supplied with all necessary cold and hot water controls and are fitted with a mid position 3 port diverter valve for control of central heating and domestic hot water.

The VANTAGE cylinders are prefitted with an operating thermostat for controlling the water temperature. VANTAGE cylinders are also provided with an auxiliary back up electric immersion heater, including operating thermostat and energy cut out.

The VANTAGE cylinders operate using a mains water pressure supply and do not require a feed from a cold water storage tank. The VANTAGE cylinders have 22 mm D. H. W. outlet and cold water mains inlet connections for optimum flow rate. To achieve optimum performance from the VANTAGE an adequate cold water mains supply pressure and flow rate must be available (see section 7.2: Mains Water pressure).

Note To Installers

This product has been assessed and found to comply with the requirements of the Building Regulations for unvented hot water storage systems and must not be altered or modified in any way.

The installation must be carried out by a competent person and be in accordance with the relevant requirements of the Local Authority, Building Regulations, Building Standards (Scotland) Regulations and the by-laws of the local Water Undertaking. The installation is subject to Building Regulation approval, notify the Local Authority of intention to install. In the event of parts replacement, use only genuine spare parts supplied by Vaillant Ltd.

Check that the cylinder has been supplied with the following:

- Packed inside cylinder carton

Tundish, cylinder drain valve, appliance top cover (including operating thermostat), functional water controls pack, installation and user instructions.

- Packed in separate carton

Expansion vessel (12 litre for VANTAGE 120/150, 18 litre for VANTAGE 200).


Prior to installation, ensure that the VANTAGE cylinder is stored upright in dry conditions. The VANTAGE must be kept upright during transportation.

Please also refer to "General Requirements" in the installation instructions supplied with the Vaillant boiler.


2 Technical data

	Vantage 120	Vantage 150	Vantage 200	Unit
Nominal storage capacity	120	150	200	litres
Nominal DHW flow from VANTAGE 120/150 VANTAGE 200	15 l/min @ 60 °C 20 l/min @ 60 °C			
Maximum water supply pressure	10			bar
Maximum primary circuit pressure	2.5			bar
Expansion vessel charge pressure	4			bar
Operating pressure	3.5			bar
Net weight	70	82	101	kg
Weight (full)	190	232	301	kg
Cylinder connections:				
Cold mains inlet	22 mm compression			
D.H.W. outlet	22 mm compression			
Balanced pressure cold water outlet	22 mm compression			
Secondary return	G ^{3/4}			
Primary flow	22 mm compression (on 3 port valve)			
Primary return	22 mm compression			
Electrical connections:				
3 kW Immersion heater	230/240 V, 50 Hz			
Three port valve	230/240 V, 50 Hz			
Cylinder thermostat	230/240 V, 50 Hz			

2 Technical data



3 Dimensions



VH 382/3 (Redesign)

Fig. 2 (all dimensions in mm)

	a	b	c	d	e	f
Vantage 120	768	900	797	560	655	268
Vantage 150	961	1086	983	600	675	261
Vantage 200	1231	1356	1253	600	675	261

3 Dimensions





Fig. 3

		THERMOcompact and ecoMAX System boilers		
		THERMOcompact		ecoMAX
		615 E, 620 E, 624 E, 628 E		613/2 E, 618/2 E, 622/2 E
Vantage cylinder	120	A	1845	1910
	150		2045	2110
	200		2345	2410
Vantage cylinder	120	B	2200	2200
	150		2400	2400
	200		2700	2700
		C	305	240
		D	145	190

Table 1



VIH 360/O (Redesign)

Fig. 4 Connection details

- A Primary flow from boiler
- B Heating flow
- C Primary return to boiler
- D Mains cold water inlet
- E Domestic hot water outlet
- F Temperature and pressure relief valve discharge
- G Sacrificial anode
- H Primary circuit air release valves
- I Secondary return connection

4 Applications

The Vaillant VANTAGE may **only** be connected to a Vaillant boiler.

No other indirect heat source may be used.

The following Vaillant boilers are available for use with the VANTAGE cylinders:

THERMOcompact system boilers

615 E (VU 152-5)

620 E (VU 202-5)

624 E (VU 242-5)

628 E (VU 282-5)

ecoMAX - Condensing system boilers

613/2 E (VU 126)

618/2 E (VU 196)

622/2 E (VU 246)

4.1 Typical applications

- Single bathroom property:
VANTAGE 120
- Single bathroom property with an en-suite shower room:
VANTAGE 120 / 150
- Two bathroom property:
VANTAGE 150
- Two bathroom property with an en-suite shower room:
VANTAGE 150 / 200
- Larger properties:
VANTAGE 200

Commercial use: size depending upon hot water requirements



Note:

1 Select the appropriate Vaillant boiler to match the heating load (with the normal allowance for heating up from cold) plus an allowance for heating the hot water cylinder. Typically it is practice to allow an additional 2-3 kW for the hot water production.

2 Consideration should be given to the use of a larger size of cylinder than shown above where high water demands are likely.

5 Functional diagrams

5.1 Functional diagram of the primary circuit




Fig. 5

- 1 Vaillant boiler
 - 2 VANTAGE cylinder
 - 3 Circulating pump
 - 4 3 port diverter valve
 - 5 Immersion heater
-
- A Boiler flow
 - B Boiler return
 - C C/H flow
 - D C/H return

5 Functional diagrams

5.2 Functional diagram of the secondary connections




Fig. 6

- 1 Temperature and pressure relief valve
 - 2 Expansion relief valve combined with check valve
 - 3 Pressure limiting valve combined with strainer
 - 4 DHW thermostat pocket
 - 5 Expansion vessel
 - 6 Secondary return connection
-
- A Cold water mains inlet
 - B Balanced pressure cold water outlet
 - C DHW outlet
 - D Tundish
 - E Cylinder drain point

6 Functional description

6.1 D.H.W. Temperature Control

The VANTAGE is supplied fitted with a user adjustable domestic hot water (DHW) thermostat and also a 3 port mid position diverter valve.

6.2 C.H. Control

Central heating is controlled by the fitted 3 port mid position diverter valve in conjunction with suitable external controls, such as a programmer, room thermostat or thermostatic radiator valves. The external electrical controls should be wired to the 3 port valve and cylinder thermostat in the normal way, as shown in section 8.4.2, VANTAGE Electrical Connections and Controls. No additional motorised valves are necessary.

6.3 Primary Circuit

The VANTAGE cylinder is provided for connection to the flow and return of any Vaillant wall hung system boiler. All Vaillant wall hung system boilers have the following components built-in:

- Sealed primary system equipment (expansion vessel, pressure relief valve and pressure gauge)
- Circulating pump
- Automatic primary system by-pass
- Boiler overheat thermostat

The 3 port valve is supplied fitted to the cylinder for easy connection to the primary flow from the Vaillant boiler, and the heating flow. No additional motorised valves are required.

6.4 Secondary System

The VANTAGE is provided with all necessary safety and control devices for unvented DHW operation.

These are as follows:

- A** A prefitted temperature and pressure relief valve (90 °C, 7 bar) (An additional overheat thermostat is contained within the Vaillant boiler).
- B** Expansion relief valve (6.0 bar) incorporating a non return valve.
- C** Pressure limiting valve (3.5 bar) incorporating a line strainer.

The VANTAGE cylinder is supplied with a separately packed expansion vessel.


- VANTAGE 120 / 150:
12 Litre vessel (Art no. 2370051)
- VANTAGE 200:
18 Litre vessel (Art. no. 2370052)

6.5 Immersion Heater

A 3 kW immersion heater is fitted to provide an auxiliary back-up means of DHW.


The immersion heater is fitted to the inspection flange, located in the side of the cylinder.

The immersion heater is designed for use in unvented installations and contains a safety overheat thermostat in addition to the operating thermostat.

 **Note:**
Only the correct immersion heater containing a safety overheat thermostat may be used for replacement (see table 2).
Vantage 120 - 200 equipped with heater type Redring LU 11 TC.

6.6 Secondary Return

For larger systems incorporating long pipe runs a secondary return connection is provided on the top of the cylinder.


 **Note:**
A recirculation system incorporating a suitable non ferrous pump may be connected into this point.

7 Installation requirements

7.1 Siting

Locate the VANTAGE in the building in the most convenient position ensuring that:

- The discharge pipe from the tundish can be installed with a minimum fall of 1:200 and can be terminated in a safe and visible position (see section 7.5 Discharge pipework).
- The base chosen for the unit is level and capable of supporting the weight of the cylinder when full (see section 2: Technical Data).
- The installation site is frost-free. If necessary provide a frost protection thermostat.
- Access is available for user operation of the DHW temperature control on the cylinder.
- Suitable clearances exist to allow installation, checking and repressurising of the expansion vessel.
- The installation site chosen does not result in excessive "dead leg" distances, particularly to the point of most frequent use.

 **Note:**
For larger systems incorporating long pipe runs a secondary return connection is provided on the top of the cylinder. A recirculation system incorporating a suitable non ferrous pump may be connected into this point.

- A suitable cold mains water supply pipe can be provided to the VANTAGE direct from the main water stop valve of the building.

7 Installation requirements

7.2 Mains Water Pressure

The DHW performance of an unvented cylinder installation will correspond to the available mains water supply pressure and flow rate. To achieve optimum performance from the VANTAGE a suitable cold mains water supply must be available, i. e. the measured static pressure from the incoming mains water supply should be at least 2.0 bar. A corresponding flow rate at least 20-25 l/min should be available.



Note:

Mains water pressures will reduce during periods of peak demand. Ensure that measurements are taken during these periods.

Once the available mains supply pressure and flowrate is known the respective flowrate from the VANTAGE can be obtained from fig. 7.

Example:

If the measured cold mains supply pressure is 2 bar static and the cold mains flow rate available is 30 l/min, the available flow rate of mixed water at 40 °C will be 25 l/min (from 15 l/min hot water from the VANTAGE k 60 °C together with 10 l/min cold water @ 10°C).

The VANTAGE will operate satisfactorily with water supply pressures below 2 bar although flow rates will be reduced. If the supply pressure is below 1 bar the VANTAGE unvented storage cylinder should not be installed. Contact Vaillant Ltd for details on alternative hot water supply systems.

In order to minimise frictional losses minimum 3/4 inch bore is recommended for new cold mains supply pipework into the dwelling although satisfactory performance can be achieved with 1/2 inch bore pipework.




Fig. 7

7.3 Secondary System

To achieve optimum distribution of the water supply it is important that the water system pipework and terminal fittings are correctly sized and balanced. The tee-off supply to the bath outlet should be in 15 mm pipework. The tee-offs to sinks and basins should be in 10 mm pipework. Terminal fittings should be suitable for mains pressure operation and taps should be of the aerated type to prevent splashing.

Some designs of terminal fittings may allow excessive flow rates resulting in user inconvenience and starvation of other outlets. In these circumstances provide a valve in the supply to that terminal fitting in order that the flow rate can be regulated.

If the VANTAGE is being installed to existing pipework with a 22 mm run to the bath terminal fittings and/or 15 mm to sinks/basins, an adjustable valve should be fitted in the supply to each outlet: By adjustment of these valves, flow rates to fittings can be regulated to achieve correct system balancing.

If the water capacity of the additional secondary pipe-work exceeds

20 litres (VANTAGE 120 or 200) or
10 litres (VANTAGE 150) an
additional expansion vessel may be required.

Pipe capacities for copper tube are:

15 mm	0.13 l/m
22 mm	0.38 l/m
28 mm	0.55 l/m

The cylinder may be drained completely for maintenance works via the drain valve (E, fig. 6) after first turning off the water supply to the cylinder and opening the hot draw off taps. Adequate access to the drain valve must therefore be available.

7 Installation requirements

7.4 Pipework - Primary Circuit

The primary circuit pipework between the Vaillant boiler and the VANTAGE should be installed using copper tube of minimum size 22 mm.

If the distance between the boiler and the cylinder is excessive, a larger pipe diameter may be necessary. It is not necessary to install a circulating pump in this pipework because all Vaillant wall mounted boilers contain a built-in circulating pump.

With the VANTAGE connected to a Vaillant boiler the remaining pump head available, at a flow rate corresponding to 20 °C temperature difference, is given in table 3.

System Pipework should be sized such that the resistance of the heating circuit offering the greatest resistance to flow (the index circuit) does not exceed this figure.

Boiler	Pump head available to heating circuit (m)
THERMOcompact 615 E	2,5
THERMOcompact 620 E	2,5
THERMOcompact 624 E	2,5
THERMOcompact 628 E	2,5
ecoMAX 613/2 E	2,5
ecoMAX 618/2 E	2,5
ecoMAX 622/2 E	2,5

7.5 Discharge Pipework

The outlet connections of both the temperature and pressure relief valve and expansion relief valve should be connected in 15 mm copper tube to the tundish supplied.

The tundish should be installed vertically, as close to the VANTAGE as possible and within 500 mm of the temperature and pressure relief and expansion relief valve outlets. It must be positioned away from any electrical components and installed in the same space as the VANTAGE cylinder.

The discharge pipework must be installed using minimum 22 mm copper pipework from the 1" inch BSP female connection on the tundish to a safe and visible discharge point. There must be a vertical section of pipe at least 300 mm long, below the tundish before any bends or elbows in the pipework. Increase the diameter of the pipework if the total resistance of the discharge pipework exceeds the figures shown in table 4.

Minimum size of discharge pipework from Tundish	Maximum total resistance allowed expressed as a length of straight pipe (i. e. no elbows or bends)	Resistance created by each elbow or bend
22 mm	up to 9 m	0.8 m
28 mm	up to 18 mm	1.0 m
35 mm	up to 27 mm	1.4 m

Example

22 mm discharge pipe having 4 elbows and a length of 7 m from the tundish to the discharge point:

$$\begin{aligned}
 &\text{Resistance for 4 elbows} \\
 &\text{at 0.8 m each} \qquad \qquad \qquad = 3.2 \text{ m} \\
 &\text{Resistance of discharge pipe} = \underline{7.0 \text{ m}} \\
 &\text{Total Resistance} \qquad \qquad \qquad = 10.2 \text{ m}
 \end{aligned}$$

The total resistance of the discharge pipework is greater than the maximum allowed for 22 mm pipework (9 m). Therefore calculate the next largest size.

28 mm discharge pipe with 4 elbows and 7 m length from tundish to discharge point.

$$\begin{aligned}
 &\text{Resistance for 4 elbows} \\
 &\text{at 1.0 m each} \qquad \qquad \qquad = 4.0 \text{ m} \\
 &\text{Resistance of discharge pipe} = \underline{7.0 \text{ m}} \\
 &\text{Total Resistance} \qquad \qquad \qquad = 11.0 \text{ m}
 \end{aligned}$$

The total resistance of the discharge pipework is less than the maximum allowed for 28 mm pipework (18 m) therefore the discharge pipework size is acceptable.

7 Installation requirements




Fig. 8




Fig. 8a

Under fault conditions, the discharge warning pipe can emit water at near boiling temperature. Ensure the discharge pipe terminates at a safe position where there is no risk of contact with hot water by persons in or about the building.

A suitable position for the discharge point is ideally below a fixed grating and above the water seal in a trapped gully. Downward discharges at low level, i. e. up to 100 mm above external surfaces such as car parks, hard standings, grassed areas, etc. are acceptable providing that where children may play or otherwise come into contact with discharges a wire cage or similar guard is positioned to prevent contact, whilst maintaining visibility.

Do not fit any valves or taps to the discharge pipework. Ensure the pipework has at least 1:200 fall continuously from the tundish to the discharge point. The discharge pipe from the pressure relief valve of the Vaillant boiler may be teed-into the discharge pipework from the VANTAGE downstream of the tundish.

7.5.1 High Level Termination

Providing that the point of termination is such that persons in or around the building will not be endangered should discharge take place, the method of termination shown in fig. 8a is satisfactory. Examples of points to consider when deciding whether a location for the high level discharge is suitable are:

- The possibility, taking into account wind effect, that someone may be in the path of the water being discharged and if so, whether the temperature of the discharge water will have been sufficiently reduced to not be dangerous. Thermal conductivity of the structure's surface, climatic conditions and location and orientation of the discharge pipe may or may not have an effect on reducing the temperature of the discharge water.
- The location of windows and similar openings.
- The likelihood of a pram being left beneath the point of discharge.
- The ability of the structures surface to withstand near boiling water.
- The possibility of ice formation if water is discharged onto pedestrian walkways.




Fig. 9

8 Installation procedure

- Unpack the VANTAGE cylinder and check the contents (detailed in section 1: notes to installers).
- Position the VANTAGE in accordance with section 7.1: Siting

Note:
 For VANTAGE 150 and 200 cylinders, remove the blanking plug from the DHW thermostat pocket located centrally at the top of the cylinder. Uncoil the sensing probe of the operating thermostat and insert it FULLY into the pocket. Secure the probe in position by fitting the retaining clip supplied (the VANTAGE 120 thermostat probe is factory fitted).

8.1 Primary pipework

The 3 port valve is supplied prefitted to the VANTAGE cylinder. The three ports of the valve are marked "A", "B" and "AB" (see fig. 9).

- Connect the flow pipe from the Vaillant boiler to the "AB" port of the three port valve.
- Connect the radiator system flow pipe to the "A" port of the three port valve.

(The "B" port of the 3 port valve is already connected to the VANTAGE cylinder primary flow connection).

- Install a return pipe from the cylinder return connection to the boiler return connection.

Note:
 The primary return connection of the VANTAGE cylinder must be joined into the return pipe from the radiator circuit, and should be the last connection before the boiler.
 A balancing valve should be fitted between the cylinder return connection and the return pipe from the radiator circuit (see fig. 10). This valve should be set to ensure correct primary flow through the radiators and cylinder during simultaneous heating and hot water demand.

8 Installation procedure




Fig. 10




Fig. 11

8.2 Secondary system Pipework

- Connect the two cold water control valves together as shown in fig 11., ensuring that the orientation of the valves, when installed in the cold mains supply, allows the 15 mm outlet of the expansion relief valve to be connected to the tundish.

Note:

The Expansion relief / non return valve has a R 3/4 connection, and is supplied fitted with a PTFE ring to ensure a watertight seal when screwed into the pressure limiting valve (separate instructions are supplied with the control valves).


- Provide a cold water mains supply to the VANTAGE. To ensure optimum performance from the VANTAGE, and particularly in installations where the balanced pressure cold water outlet (2, fig. 11) is to be used, the pipework provided from the building mains stop valve to the VANTAGE cylinder should be minimum 22 mm copper tube.
- Install the assembled cold water control valves (fig. 11) in the cold mains supply at a convenient position adjacent to the VANTAGE cylinder, ensuring adequate space exists for service access.




Important

No valve shall be installed between the assembled cold water control valves and the cylinder.

- Connect the expansion vessel to the installed water controls by either:
 - i. Screwing the vessel directly into the control assembly at the purpose provided connection (3, fig. 11) or,
 - ii. Connecting the vessel to the control assembly via copper pipe or a suitable approved flexible connection hose, ensuring that the vessel is adequately supported.

 **Note:**
An optional "Remote Expansion Vessel Mounting Kit" (Art no. 2378083) is available for use with VANTAGE cylinders. The kit contains a wall mounting bracket and a 1 metre flexible connection.

- Connect the balanced pressure cold water supply (if required) to the pressure limiting valve.

 **Note:**
In areas where the mains water pressure is high (4 bar or above) the cold water supply to a bath or shower mixer valve can be taken from the balanced pressure cold water outlet (2, fig. 11) of the cold water controls. This will ensure that both hot and cold supplies to the mixer valve are at approximately the same pressure. The cold water supply for all other terminal fittings should be feed into the cold water supply pipework to the VANTAGE upstream of the cold water controls.


- Connect the DHW outlet pipework to the 22 mm domestic hot water outlet on the VANTAGE (E, fig. 4). Continue with 22 mm size pipe to the first tee fitting after which 15 mm pipework should be adequate. If the pipe runs are of excessive length or there are several terminal fittings supplied, extend the length of pipework in 22 mm. (See 7.3: Secondary System.)

8.3 Safety valve discharge pipework

- Connect the temperature/pressure relief and expansion relief valves to the tundish and install the discharge pipework from the tundish in accordance with section 7.5: Discharge Pipework.

8 Installation procedure

VANTAGE 120, 150 and 200 installation



VH 374/0 (Redesi:gn)

Fig. 12

- A Primary flow from boiler
- B Heating flow
- C Primary return to boiler
- D Main cold water inlet
- E Domestic hot water outlet
- F Temperature and pressure relief valve discharge
- G Sacrificial anode
- H Primary circuit air release valves
- J Pressure limiting valve and strainer
- K Combined expansion relief and check valve
- L Connection point for expansion vessel
- I Secondary return connection




Fig. 13

8.4 Electrical connections and controls

8.4.1 Immersion Heater



Warning:

The immersion heater must be earthed.

Install a separate electrical supply to the immersion heater in accordance with the current IEE wiring regulations (BS 7671). The immersion heater must be wired in 2.5 mm² heat-resisting cable from a double pole isolating switch. The circuit must be protected by a 13 amp fuse. The connection details for the immersion heater are shown in fig. 13.



Important:

The immersion heater incorporates an energy cut-off device and must not under any circumstances be replaced by a standard immersion heater.

Only a correct genuine Vaillant spare part is permitted.

8.4.2 VANTAGE Electrical Connections and Controls



Warning:

The VANTAGE cylinder must be earthed.

The Vaillant VANTAGE and accompanying Vaillant boiler may be controlled using various programmers and room thermostats, details of which are given in section 8.4.3: Control Options.

The VANTAGE cylinder has a prefitted cylinder thermostat, supplied with 1 m of 3 core and earth flying lead. The colour coding for the cylinder thermostat connection is as follows:

Brown wire	Common
Blue wire	DHW calling
Black wire	DHW satisfied
Green / yellow wire	Earth

Connections to wiring centre

- Provide a wiring centre adjacent to the VANTAGE cylinder to make the electrical connections (see fig.14).
- Connect the Vaillant boiler terminals to the corresponding terminals of the wiring centre.
- Connect the VANTAGE cylinder thermostat flying lead and the 3 port valve flying lead to the terminals of the wiring centre.
- Connect the terminals of the programmer and room thermostat to the terminals of the wiring centre.
- Connect a 3 amp fused mains supply to the terminals of the wiring centre.



NOTE:

All wiring must be carried out in accordance with BS 7671: Requirements for electrical installations (IEE Wiring Regulations, 16th edition).


8 Installation procedure

8.4.3 Control options - system wiring scheme

Important 1-10 must go to the corresponding number in the wiring centre.

Connection details for control systems utilising 3 port motorised valve via external wiring centre/junction box

Diagram only applies to the specific controls mentioned



Anschluss VtH Vantage 1

Fig. 14

Connection details between programmer and wiring centre.																												
Lifestyle LP241, LP 522, LP 722	<table border="1"> <tr><td>N</td><td>L</td><td>1</td><td>2</td><td>3</td><td>4</td></tr> <tr><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td></tr> <tr><td>5</td><td>3</td><td>8</td><td>not used</td><td>7</td><td>6</td></tr> </table>	N	L	1	2	3	4	↓	↓	↓	↓	↓	↓	5	3	8	not used	7	6									
N	L	1	2	3	4																							
↓	↓	↓	↓	↓	↓																							
5	3	8	not used	7	6																							
Tempus 6, Tempus 7	<table border="1"> <tr><td>E</td><td>N</td><td>L</td><td>1</td><td>2</td><td>3</td><td>4</td></tr> <tr><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td></tr> <tr><td>⊕</td><td>5</td><td>3</td><td>8</td><td>not used</td><td>7</td><td>6</td></tr> </table>	E	N	L	1	2	3	4	↓	↓	↓	↓	↓	↓	↓	⊕	5	3	8	not used	7	6						
E	N	L	1	2	3	4																						
↓	↓	↓	↓	↓	↓	↓																						
⊕	5	3	8	not used	7	6																						
Danfoss Randall CP 715, FP715 Note: *Earth not required	<table border="1"> <tr><td>E</td><td>N</td><td>L</td><td>1</td><td>2</td><td>3</td><td>4</td></tr> <tr><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td></tr> <tr><td>*</td><td>5</td><td>3</td><td>8</td><td>not used</td><td>7</td><td>6</td></tr> </table>	E	N	L	1	2	3	4	↓	↓	↓	↓	↓	↓	↓	*	5	3	8	not used	7	6						
E	N	L	1	2	3	4																						
↓	↓	↓	↓	↓	↓	↓																						
*	5	3	8	not used	7	6																						
Grässlin Towerchron QE2, QM2	<table border="1"> <tr><td>N</td><td>L</td><td>1</td><td>2</td><td>3</td><td>4</td></tr> <tr><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td></tr> <tr><td>5</td><td>3</td><td>8</td><td>not used</td><td>7</td><td>6</td></tr> </table>	N	L	1	2	3	4	↓	↓	↓	↓	↓	↓	5	3	8	not used	7	6									
N	L	1	2	3	4																							
↓	↓	↓	↓	↓	↓																							
5	3	8	not used	7	6																							
Honeywell ST699B, ST799A Note: Link L - 5 - 8	<table border="1"> <tr><td>L</td><td>N</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td></tr> <tr><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td></tr> <tr><td>3</td><td>5</td><td>6</td><td>not used</td><td></td><td>7</td><td>8</td><td></td></tr> </table>	L	N	3	4	5	6	7	8	↓	↓	↓	↓	↓	↓	↓	↓	3	5	6	not used		7	8				
L	N	3	4	5	6	7	8																					
↓	↓	↓	↓	↓	↓	↓	↓																					
3	5	6	not used		7	8																						
Honeywell ST6200, ST6300, ST6400	<table border="1"> <tr><td>N</td><td>L</td><td>1</td><td>2</td><td>3</td><td>4</td></tr> <tr><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td></tr> <tr><td>5</td><td>3</td><td>8</td><td>not used</td><td>7</td><td>6</td></tr> </table>	N	L	1	2	3	4	↓	↓	↓	↓	↓	↓	5	3	8	not used	7	6									
N	L	1	2	3	4																							
↓	↓	↓	↓	↓	↓																							
5	3	8	not used	7	6																							
Horstmann Channel Plus H21, H27 Note: *Earth not required, Link L - 2 - 5	<table border="1"> <tr><td>E</td><td>N</td><td>L</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr> <tr><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td></tr> <tr><td>*</td><td>5</td><td>3</td><td>7</td><td></td><td>8</td><td>6</td><td></td><td>not used</td></tr> </table>	E	N	L	1	2	3	4	5	6	↓	↓	↓	↓	↓	↓	↓	↓	↓	*	5	3	7		8	6		not used
E	N	L	1	2	3	4	5	6																				
↓	↓	↓	↓	↓	↓	↓	↓	↓																				
*	5	3	7		8	6		not used																				
Siemens-Landis & Staefa RWB2, RWB9	<table border="1"> <tr><td>N</td><td>L</td><td>1</td><td>2</td><td>3</td><td>4</td></tr> <tr><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td></tr> <tr><td>5</td><td>3</td><td>8</td><td>not used</td><td>7</td><td>6</td></tr> </table>	N	L	1	2	3	4	↓	↓	↓	↓	↓	↓	5	3	8	not used	7	6									
N	L	1	2	3	4																							
↓	↓	↓	↓	↓	↓																							
5	3	8	not used	7	6																							
Potterton Myson EP 2001, EP 3001, EP 6002 Note: Link L - 5	<table border="1"> <tr><td>E</td><td>N</td><td>L</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr> <tr><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td></tr> <tr><td>⊕</td><td>5</td><td>3</td><td>8</td><td>not used</td><td>7</td><td>6</td><td></td></tr> </table>	E	N	L	1	2	3	4	5	↓	↓	↓	↓	↓	↓	↓	↓	⊕	5	3	8	not used	7	6				
E	N	L	1	2	3	4	5																					
↓	↓	↓	↓	↓	↓	↓	↓																					
⊕	5	3	8	not used	7	6																						
Sunvic Select 207	<table border="1"> <tr><td>N</td><td>L</td><td>1</td><td>2</td><td>3</td><td>4</td></tr> <tr><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td><td>↓</td></tr> <tr><td>5</td><td>3</td><td>8</td><td>not used</td><td>7</td><td>6</td></tr> </table>	N	L	1	2	3	4	↓	↓	↓	↓	↓	↓	5	3	8	not used	7	6									
N	L	1	2	3	4																							
↓	↓	↓	↓	↓	↓																							
5	3	8	not used	7	6																							

Anschluss VIH Vantage 2

Fig. 15

9 Commissioning

9.1 Filling Secondary D.H.W. Circuit



Note:

Do not manually open the temperature and pressure relief valve or expansion relief valve for venting purposes (any foreign matter in the pipework may cause damage to the valve seats).

- Ensure that the cylinder drain valve (E, fig. 6) is closed.
- Open all the hot and cold water taps or other terminal fittings.
- Open the mains water supply to the VANTAGE and continue filling until water runs freely from the terminal fittings, ensuring all air pockets are purged.
- Close the terminal fittings and check the system for leaks.

The system should now be thoroughly flushed.

- Open hot water taps at opposite ends of the system and allow water to discharge for at least 5 minutes.
- Close the hot water taps.

9.2 Filling the Primary Circuit



Note:

Do not use boiler pressure relief valve for venting purposes.

- The complete primary C.H. system must be flushed out with both cold and hot water. Fill and vent the central heating system as detailed in the boiler installation instructions.
To assist with this operation set the manual override lever on the 3 port diverter valve (fig. 9) to the MANUAL position, and lock in this position by pushing the lever into the valve head.
- Vent air from the VANTAGE heating coil from the venting points (H, fig. 4).
- Completely drain the CH system, then refill and vent.
- Reset the lever on the 3 port valve to the "AUTO" position by releasing the manual operating lever from the valve head (pull outwards).
For commissioning purposes and to reduce the time for the cylinder contents to reach temperature, set the cylinder hot water thermostat knob to setting 3 (approx. 40 °C).
- Operate the boiler as in section 9.3 until both the cylinder has reached temperature and all radiators in the system are hot. Then once again drain the complete CH system to remove residues from the pipework and refill and vent again as above.
- Reset the manual operating lever on the 3 port valve to the "AUTO" position once the system has been refilled and vented.

9.3 Operating the Vaillant Boiler

- Ensure the boiler mains switch is turned on.
- Ensure that the programmer and thermostats are calling for heat.
- Check that the boiler fires and heats the cylinder contents and the radiators according to the DHW and room thermostat settings.
- Carry out the commissioning and testing procedures detailed in the installation instructions supplied with the Vaillant boiler.
- Upon completion of the commissioning procedures, set the DHW thermostat knob on the VANTAGE to setting 5-6, approx. 60 °C, and set the back up immersion heater (fig. 13) thermostat to 60 °C.

9.4 User's Instructions

Hand the instructions for use to the user for retention and instruct in the safe operation of the boiler and cylinder. Advise the user of the operation of the cylinder thermostat, and that normally a setting of 5-6, which gives a stored water temperature of approximately 60 °C is adequate.



Note:

In hard water areas the DHW temperature setting should not exceed this setting to avoid possible scale build-up.

Advise the user of the precautions necessary to prevent damage to the system and to the building if the system does not remain operative during frost conditions.

Advise the user that the immersion heater is provided as a back up means of water heating and is not intended for use at the same time that the Vaillant boiler is heating the cylinder.

Finally, advise the user that for continued efficient and safe operation, the Vaillant boiler and VANTAGE cylinder should be serviced at least once a year by a qualified servicing company. It is important and strongly recommended that arrangements are made for a maintenance agreement with a qualified servicing company to ensure regular servicing of the Vaillant boiler and VANTAGE cylinder.

Please contact Vaillant Service Solutions (0870 - 6060777) for further details.



Note:

Leave installation, servicing and user instructions with the user.

10 Maintenance

The following maintenance work has to be carried out annually by the competent installer or Vaillant Service Solutions.

- Inspection of pressure/temperature relief valve and expansion relief valve.
Manually operate each valve by twisting the operating cap, and check if water flows unobstructed via the tundish to the discharge point. Ensure that both valves re-seat satisfactorily.
- Check pressure of expansion vessel.
- Turn off mains water supply and open nearest hot water tap to depressurise the secondary water system. Check the expansion vessel charge with a pressure gauge at the test point. If the pressure is below 3.5 bar, top up with suitable air pressure pump.
- Every 2 years check corrosion protection anode for wear.
- The anode has a life expectancy of approximately 6 years. It should be replaced if the diameter is less than 12 mm.

Servicing procedures for the Vaillant boiler are contained in the boiler installation and servicing instructions.



Note:

In the event that parts require replacement, use only genuine spare parts supplied by Vaillant Ltd.

11 Fault finding

Note:
 Only genuine spare parts supplied
 by Vaillant Limited must be used.





Fig. 16



V/H_Fault_B

Fig. 17

11 Fault finding




Fig. 18




Fig. 19

Head Office
Vaillant Ltd., Vaillant House,
Medway City Estate, Trident Close,
Rochester, Kent ME2 4EZ

Sales	01634 292310
Service Solutions	0870 6060 777
Technical Advice	01634 292392
Training	01634 292370